

# VEI Systems Installation Instructions

## D1-OTF-FQM-Mx – Dual Gauge – Oil Temperature (deg-F) & Fuel-Level

Please read these instructions completely before beginning installation to ensure that you have the tools and skills necessary for installation and operation of this instrument. If you are not sure that you can perform the installation safely, then consult a qualified installer. Further instructions available at [www.VEISystems.com/technical.html](http://www.VEISystems.com/technical.html).

### FEATURES

This dual-function instrument monitors engine oil temperature and fuel level and displays them simultaneously on two independent displays on the same gauge. Each of the two functions have upper- and lower-threshold alarms that are user configurable for the specific application vehicle.

### MOUNTING


Install the unit through the front of the mounting hole in the dash pod or panel. If you are making a custom dash panel, you will need to drill a 2-1/16" hole. Slide the clamp onto the 2 studs on the back of the instrument. Secure with the 2 thumb-nuts. Use a small drop of threadlocker or nail polish on the thumb-nuts to prevent them from loosening under vibration.

Use oil-temperature sender SEN-T320D. Mount the sender on the engine block at an appropriate location (generally be where there was an existing oil-temperature switch or sender). You can tee off the existing sender or switch if you need to keep both. If you are unsure of a suitable location, consult the vehicle service manual or a qualified installer for. CAUTION: teflon tape or compound may eventually break off and get into the oil stream, causing blockage in the oil passages and cause engine damage. If you experience leaks, try tape only on the back half of the threads on the sender. The engine must be well grounded to the chassis & battery. If using teflon tape, measure the resistance between the outer body of the temperature sender and the engine block to ensure good electrical contact.

The fuel-level gauge is designed to work with most stock senders, or we can provide a sender if required. One side of the sender should be grounded (usually the body).

### WIRING

The wires should be connected as below using crimp-on butt-splice connectors, or soldered and sealed with heat-shrink tubing. Before connecting any wires, you should either disconnect the battery power, or carefully connect the wires in the order shown. If not, you may damage the instrument. Use an existing fuse in the fuse panel, or an external fuse to supply power to the instrument. The D1 series instruments use approx. 130mA of current average and approx. 210mA maximum, so ensure the fuse is sized appropriately. For a typical 6- or 7-gauge setup, a single 5 Amp fuse is good.



- BLACK (Thick) -- connect to a solid chassis ground under the dash, or directly to the battery. You may need to expose the metal connection point under the dash by scraping or lightly sanding it. A ring terminal and a screw should work well in most cases.
- RED -- connect this to a source of **switched** +12V power. This will usually be found at or near the ignition switch, and will usually have a relay wired through the ignition switch. An alternate source of this is a switched power line from a nearby light or accessory (radio, etc). If you are unsure that the wire can support the power required for the instrument, then use an external relay.

- GREEN – connect this wire to the positive line (+12V) from the headlight switch. When this line receives a positive voltage, the gauge will use the “park-lights” brightness setting. Alternatively, if setting up a racing-mode display, this can be connected to a separate mode switch (12V or 0V signal).
- WHITE -- connect this wire to top stud on the OIL-temperature sender.
- GREY -- connect this wire to white wire on the FUEL-level sender.

## OPERATION

Press and hold the button for a few seconds to change the mode. Press and release quickly (tap the button) to change the setting in any mode. Modes are as follows:

MODE	DISPLAY	SETTINGS
Normal	(oil temp and fuel level)	Shows oil temperature in upper display and fuel level in lower display, unless display channels were swapped (explained below). Tap to turn off audible alarm.
Channel swap	Ch1 / Ch2	Allows you to swap the position of the upper & lower displays if required.
Set low oil-temp alarm	L1 . 150	Sets the low OIL-temp alarm threshold from 150 to 190 deg-F.
Set high oil-temp alarm	H1 . 235	Sets the high OIL-temp alarm threshold from 200 to 320 deg-F.
Set low-fuel warning level	LO / 5	Display shows percentage warning level from 0 to 50%.
Set startup mode	run / CAL	Setting this to “CAL” will cause the gauge to enter calibration mode on next power-up.
Brightness Regular	Br . 9	Last digit shows regular brightness level from 1 to 9.
Brightness park-lights on	BP . 1	Last digit shows brightness level with lights on from 1 to 9.

## WARRANTY & LIABILITY

Neither VEI Systems, nor its dealers or agents shall be liable in any way, for any damage, loss, injury or other claims, resulting from the installation or use of this product. By purchasing or installing this product, you assume all liability of any kind connected with the use and/or application of this product. If you are unsure that you can safely install and use this product, consult a qualified installer or mechanic. The warranty on this product covers only the product itself for a period of 1 year from the date of purchase, and it will be at our discretion to repair or replace the affected parts. No user serviceable parts inside. Warranty void if product enclosure opened.